

# The Attached Garage From the Inside

Two heights you have missed, and the conditions that are and are not hazards.

## The numbers here

|                                                                              |       |
|------------------------------------------------------------------------------|-------|
| Overhead garage door operator wall control — at least this far off the floor | 60 in |
| Overhead garage door manual release rope — at least this far above the floor | 72 in |

### YOU HAVE MISSED THIS 4 TIMES

The overhead garage door operator control at the wall should be at least \_\_\_\_ off of the floor.  
**60 inches.**

### YOU HAVE MISSED THIS

The overhead garage door manual release rope should be installed at least \_\_\_\_ above the garage floor.  
**72 inches.**

Both heights exist to keep a child from operating the door. Sixty inches for the button, seventy-two for the rope — the rope is higher because it hangs down and a hanging handle is easier for a child to reach than a button on the wall. Five feet and six feet.

**Internal reversing mechanism** The part of the opener that causes the door to reverse when it hits an obstruction.

**Garage floor level** Should be lower than the main floor level, so gasoline vapors, which are heavier than air, cannot flow into the house.

## What is not a hazard

### YOU HAVE MISSED THIS 2 TIMES

When evaluating an attached garage, which condition would not be considered a potential safety hazard?

**The wood framing members are covered with plasterboard.**

Covered framing is the required condition, not a defect — it is the fire separation doing its job. On a question asking which is NOT a hazard, look for the option describing correct construction.

The same shape appears with flooding: asked which condition would NOT indicate flood potential in a garage, the answer is that the garage floor is pitched toward a floor drain in the slab. That is drainage working properly.

**Garbage disposal power cord** Requires a drip loop — the cord dips below the connection so water running down it drops off rather than running into the terminal.

## Say it back

Cover the page. Answer each one out loud.

1. Height for the wall control and for the manual release rope, and why they differ?
2. What does the internal reversing mechanism do?
3. Should the garage floor be higher or lower than the house floor, and why?
4. Covered wood framing in a garage — hazard or not?
5. A garage floor pitched to a floor drain — flood risk or not?
6. What does a garbage disposal cord require, and what does it do?